



Using Wudcare adhesive

- 1 Sticking a headrest block to a fuselage as an example
- 2 Mask closely round the mating surfaces. Apply glue to one face and slightly dampen the other face. Not too much! A very thin coat will be sufficient.
- 3 Bring together and hold in position while glue sets (Approx 15m)
- 4 Remove any foam that appears around joint while still soft. Masking tape prevents foam from bonding to surrounding material
- 5 Remove masking tape to reveal a perfect join!